



Emergency planning & response performance modeling

(human action impact on consequences)

Topics




Estimating Operator Response Time

Estimating Emergency Response Time

Factors affecting release volume





Typical Conversation to Solicit Estimates



Risk Analyst: "How long does it take to shutdown this pipeline?"

Operator: "I can't say. It depends."

Risk Analyst: "Depends on what?"

Operator: "Depends on where the release happens, whether we catch it

before CPM does, if we are distracted by another critical

task,....There are just too many variables."

Risk Analyst: "Can you give me your best estimate?"

Operator: "5 minutes? Wait, what is this being used for?"

Risk Analyst: "It will be an input into our risk model."

Operator: "In that case, 10 minutes."

Risk Analyst: "That seems like a very conservative estimate."

Operator: "No. There are some situations where it could take that long."

What is Monte Carlo Analysis?




Monte Carlo methods (or Monte Carlo experiments) are a broad class of computational algorithms that rely on repeated random sampling to obtain numerical results. They are often used in physical and mathematical problems and are most useful when it is difficult or impossible to use other mathematical methods. Monte Carlo methods are mainly used in three distinct problem classes: optimization, numerical integration, and generating draws from a probability distribution.

General Process:

- 1. Define a domain of possible inputs.
- 2. Generate inputs randomly from probability distributions over the domain.
- 3. Perform a deterministic computation on the inputs.
- 4. Aggregate the results.


Sociotechnical Event Sequence






Probability Distribution Functions





Estimate PDF Parameters







Release location

CPM Time to Detect Leak

Analyst Recognizes Rupture based on Leak Alarm

Analyst Recognizes Rupture based on Hydraulic Change Only

Estimated Leak Location and Determine Units to Shutdown

Connecting Carriers Shutdown (origination station booster)

Connecting Carriers Shutdown (tight-line movement)

Gravity Drain to Delivery Location

OC Supervisor Authorizes Shut-in





Release location



Beta (PERT)

CPM Detection of Leak

Analyst Recognizes Rupture based on Leak Alarm

Analyst Recognizes Rupture based on Hydraulic Change Only

Estimated Leak Location and Determine Units to Shutdown

Connecting Carriers Shutdown (origination station booster)

Connecting Carriers Shutdown (tight-line movement)

Gravity Drain to Delivery Location

OC Supervisor Authorizes Shut-in

Non-Random Variables



Constants

Product Type

Segment Length

Nominal Diameter

of Mainline Booster Stations

of Mainline Isolation Valve

Receipt Headgate Valve Travel Time

Delivery Headgate Valve Travel Time

RMOV Valve Travel Time

Third Party Origination Booster

Third Party Tight Line Movement

Calculated Variables


Speed of Sound in Product


Hydraulic Response Time

Downstream Units Run until Loss of Suction Pressure

Results









Shutdown								
Response	Time							
P5	131	(2m 11s)						
P50	153	(2m 33s)						
P60	157	(2m 37s)						
P70	162	(2m 42s)						
P80	167	(2m 47s)						
P90	174	(2m 54s)						
P95	180	(2m 60s)						
P100	209	(3m 29s)						

Detected By	Percent
CPM Alarm	6%
Hydraulic Analysis	94%

Shut-In - Time Distribution



Shut-In									
Response	Time								
P5	337	(5m 37s)							
P50	411	(6m 51s)							
P60	424	(7m 4s)							
P70	438 (7m 18:								
P80	455	(7m 35s)							
P90	478	(7m 58s)							
P95	497	(8m 17s)							
P100	581	(9m 41s)							





Release location
Spill volume
Day of the year
Day of the week
Time of day
OSRO preparation time
OSRO travel time
OSRO staging time
OSRO deployment time
River speed





Release location
Spill volume
Day of the year
Day of the week
Time of day



OSRO preparation time
OSRO travel time
OSRO staging time
OSRO deployment time
River speed



Google Travel Times		Lat	Long	Spill Volume	OSRO	1	2	3	4	5	6
	1	40.76142855	-83.29879905	457.99	MMP	53	112	107	129	118	116
Leak Points	2	40.8060379	-83.36718535	770.04	MMP	44	104	112	123	122	120
7	3	40.81514221	-83.37796581	784.91	MMP	44	104	115	120	121	119
OSROs	4	40.90531849	-83.51262494	560.49	MMP	40	101	109	125	131	129
6	5	40.95103078	-83.58401269	843.7	MMP	38	99	103	128	134	131
	6	40.99761868	-83.64869817	1,084.41	WCD	97	138	246	255	415	569
Run	7	41.02929129	-83.67032157	1,089.01	WCD	93	137	251	251	414	568
Calculate											
Clear											
Cleal											
Directions											
1. Enter one or more lat, long											
2. Click "Run"											
3. If errors occur during											
calculation, click "Run" again.											
4. Repeat process until all											
times are populated.											
5. Click "Calculate" to view											
results.											
. 55 5 66											

Leak Location

M	7	N.
	•	

Google Travel Times		Lat	Long	Spill Volume	OSRO	1	2	3	4	5	6
	1	40.76142855	-83.29879905	457.99	MMP	53	112	107	129	118	116
Leak Points	2	40.8060379	-83.36718535	770.04	MMP	44	104	112	123	122	120
7	3	40.81514221	-83.37796581	784.91	MMP	44	104	115	120	121	119
OSROs	4	40.90531849	-83.51262494	560.49	MMP	40	101	109	125	131	129
6	5	40.95103078	-83.58401269	843.7	MMP	38	99	103	128	134	131
	6	40.99761868	-83.64869817	1,084.41	WCD	97	138	246	255	415	569
Run	7	41.02929129	-83.67032157	1,089.01	WCD	93	137	251	251	414	568
Calaulata											
Calculate											
Clear											
cicai											
Directions											
1. Enter one or more lat, long											
2. Click "Run"											
3. If errors occur during											
calculation, click "Run" again.											
4. Repeat process until all											
times are populated.											
5. Click "Calculate" to view											
results.											

Spill Volume



Google Travel Times		Lat	Long	Spill Volume	OSRO	1	2	3	4	5	6
	1	40.76142855	-83.29879905	457.99	MMP	53	112	107	129	118	116
Leak Points	2	40.8060379	-83.36718535	770.04	MMP	44	104	112	123	122	120
7	3	40.81514221	-83.37796581	784.91	MMP	44	104	115	120	121	119
OSROs	4	40.90531849	-83.51262494	560.49	MMP	40	101	109	125	131	129
6	5	40.95103078	-83.58401269	843.7	MMP	38	99	103	128	134	131
	6	40.99761868	-83.64869817	1,084.41	WCD	97	138	246	255	415	569
Run	7	41.02929129	-83.67032157	1,089.01	WCD	93	137	251	251	414	568
Calculate											
Clear											
Clear											
Directions											
1. Enter one or more lat, long											
2. Click "Run"											
3. If errors occur during											
calculation, click "Run" again.											
4. Repeat process until all											
times are populated.											
5. Click "Calculate" to view											
results.											

OSRO Type



										_	
Google Travel Times		Lat	Long	Spill Volume	OSRO	1	2	3	4	5	6
	1	40.76142855	-83.29879905	457.99	MMP	53	112	107	129	118	116
Leak Points	2	40.8060379	-83.36718535	770.04	MMP	44	104	112	123	122	120
7	3	40.81514221	-83.37796581	784.91	MMP	44	104	115	120	121	119
OSROs	4	40.90531849	-83.51262494	560.49	MMP	40	101	109	125	131	129
6	5	40.95103078	-83.58401269	843.7	MMP	38	99	103	128	134	131
	6	40.99761868	-83.64869817	1,084.41	WCD	97	138	246	255	415	569
Run	7	41.02929129	-83.67032157	1,089.01	WCD	93	137	251	251	414	568
Calculate											
Clear											
Clear											
Directions											
1. Enter one or more lat, long											
2. Click "Run"											
3. If errors occur during											
calculation, click "Run" again.											
4. Repeat process until all											
times are populated.											
5. Click "Calculate" to view											
results.											




Google Travel Times		Lat	Long	Spill Volume	OSRO	1	2	3	4	5	6
	1	40.76142855	-83.29879905	457.99	MMP	53	112	107	129	118	116
Leak Points	2	40.8060379	-83.36718535	770.04	MMP	44	104	112	123	122	120
7	3	40.81514221	-83.37796581	784.91	MMP	44	104	115	120	121	119
OSROs	4	40.90531849	-83.51262494	560.49	MMP	40	101	109	125	131	129
6	5	40.95103078	-83.58401269	843.7	MMP	38	99	103	128	134	131
	6	40.99761868	-83.64869817	1,084.41	WCD	97	138	246	255	415	569
Run	7	41.02929129	-83.67032157	1,089.01	WCD	93	137	251	251	414	568
Calaulata											
Calculate											
Clear											
Cicui										<u> </u>	
Directions											
1. Enter one or more lat, long											
2. Click "Run"											
3. If errors occur during											
calculation, click "Run" again.											
4. Repeat process until all											
times are populated.											
5. Click "Calculate" to view											
results.											





Google Travel Times		Lat	Long	Spill Volume	OSRO	1	2	3	4	5	6
	1	40.76142855	-83.29879905	457.99	MMP	53	112	107	129	118	116
Leak Points	2	40.8060379	-83.36718535	770.04	MMP	44	104	112	123	122	120
7	3	40.81514221	-83.37796581	784.91	MMP	44	104	115	120	121	119
OSROs	4	40.90531849	-83.51262494	560.49	MMP	40	101	109	125	131	129
6	5	40.95103078	-83.58401269	843.7	MMP	38	99	103	128	134	131
	6	40.99761868	-83.64869817	1,084.41	WCD	97	138	246	255	415	569
Run	7	41.02929129	-83.67032157	1,089.01	WCD	93	137	251	251	414	568
Calculate											
Clear											
Cleal											
Directions											
1. Enter one or more lat, long											
2. Click "Run"											
3. If errors occur during											
calculation, click "Run" again.											
4. Repeat process until all											
times are populated.											
5. Click "Calculate" to view											
results.											
icourto.											











Minutes HH:N	,,,,,,
Min 156 2:3	6
P50 253 4:1	3
P75 290 4:5	0
P95 337 5:3	7
Max 573 9:3	3

Return to Inputs

	Miles
Min	5.3
P50	12.6
P75	14.9
P95	18.7
Max	35.4